TD Mobile Pay

Merchant Guide





COPYRIGHT © 2021 by The Toronto-Dominion Bank

This publication is confidential and proprietary to The Toronto-Dominion Bank and is intended solely for the use of Merchant customers of TD Merchant Solutions. This publication may not be reproduced or distributed, in whole or in part, for any other purpose without the written permission of an authorized representative of The Toronto-Dominion Bank.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TD is under license. Other trademarks and trade names are those of their respective owners.

NOTICE

The Toronto-Dominion Bank reserves the right to make changes to specifications at any time and without notice. The Toronto-Dominion Bank assumes no responsibility for the use by the Merchant customers of the information furnished in this publication, including without limitation for infringements of intellectual property rights or other rights of third parties resulting from its use.

Table of Contents

Who should use this guide?	1
Overview of the TD Mobile Pay Solution	1
The purpose of this guide	
Requirements	
What is the TD Mobile Pay solution?	
The card reader	3
Screens	3
TD Mobile Pay application	5
New Sale screen	
Connection Manager screen	
Menu screen	
Merchant Portal	8
Financial transactions	8
New Sale	
Select product	
Quick Sale	
New Sale - Payment	
Discounts	10
Voids and refunds	11
Voids	
Refunds	
Receipts	
Receipt example	
Resend a receipt	
Download a receipt	
Reviewing sales	
Dashboard	
Sales history	
Settlement	15
Configuration	15
Manage your product catalog	
Add a new product	
Disable or enable a product	
Delete a product	16
Manage your product categories	16
Add a category	16
Edit a Category	
Delete a category	
Manage your taxes	
Add a tax	
Edit a tax	
Disable a tax	
Delete a tax	
Customize your receipts	18

	18
View a card reader	18
Connecting to your card reader	18
Edit a card reader's name (alias)	
Reinitialize a card reader	
Deactivate a card reader	19
Adjust a card reader's volume	
Replace a card reader	
Update your account profile	
Change your account name	
Change your language preference	
Change your email	
Change your mobile number	
Security	
Change your password	
Change your authentication preference	
View your business profile	
Manage your staff / users	22
Add a new staff user account	
View your staff / user accounts	22
Reports	23
Run a report	
Navigation	23
Report label	
Detailed transactions report	
Product sales report	
Tax report	
Tax report	26
Tax report	26
Tax report	26
Tax report	26 26
Tax report	26 26
Tax report	26 26 26
Statements View merchant statements Download a statement Troubleshooting	26262626
Tax report	26262626
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA	2626262626
Tax report Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password	2626262727
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader	262626272727
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert?	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert?	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve?	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application?	
Statements View merchant statements Download a statement Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS)	
Statements View merchant statements Download a statement Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS) Remove the mobile phone app from the card reader	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS) Remove the mobile phone app from the card reader	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS) Remove the mobile phone app from the card reader Reference. Storing the card reader	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS) Remove the mobile phone app from the card reader	
Statements View merchant statements Download a statement Troubleshooting Signing in using SMS/text MFA Forgot Your Password Connecting to your card reader Accepting payment What do I do if the card reader displays a security alert? Why isn't my card reader powering on? What problems can I easily resolve? Why isn't my card reader connecting to the application? Remove the card reader from your mobile phone (Androi Remove the card reader from your mobile phone (iOS) Remove the mobile phone app from the card reader Reference. Storing the card reader	

Who should use this guide?

You would use this guide if you use the TD Mobile Pay Solution. It includes hardware functionality, performing financial transactions, configuration and troubleshooting.

Overview of the TD Mobile Pay Solution

The purpose of this guide

This guide will provide helpful information about the equipment, its features and TD Merchant Solutions. Please ensure you read this guide so that you become familiar with the capabilities of the TD Mobile Pay and how it can support your business needs.

This guide provides instruction on the use and functionality of the TD Mobile Pay solution. The provision of Visa®, MasterCard®, American Express® and/or Interac® Direct Payment merchant services to you (the user) by TD Merchant Solutions is governed by the Merchant Services Agreement and any other agreement(s) that govern the services that we may provide to you.

The use of the TD Mobile Pay solution with respect to the provision of merchant services by a third party is governed by any agreement(s) with such third party.

Requirements

- A mobile phone with the Android[™] or iOS[™] operating system
- A mobile phone that:
 - is Bluetooth® Low Energy (BLE) compatible
 - has a camera if you wish to add images to the Product catalog

What is the TD Mobile Pay solution?


The TD Mobile Pay solution is comprised of two components.

The card reader and the mobile application

The card reader and the mobile phone app work together as one solution.

- The TD Mobile Pay app is like your electronic cash register where you enter the customer's purchase and the card reader is where the customer pays for their purchase with their credit or debit card.
- On the TD Mobile Pay app you can:
 - connect to the card reader via Bluetooth.
 - review transactions.
 - perform refunds / voids,
 - administer your product catalog, and
 - administer your account.






The Merchant Portal

The merchant portal is a website that mimics the administration capabilities of the smartphone app and is accessible via web browser. You can:

- review transactions and perform refunds / voids,
- administer user accounts,
- pull reports, and review your monthly statements.

To access the TD Mobile Pay Merchant Portal, go to https://www.mobilepay.td.com/MerchantPortal/.



Functionality

Between the two components (TD Mobile Pay app / card reader and Merchant Portal) there are some overlapping functionality which allows you options as how to access information and perform tasks. Below is a list of functionality and where they can be performed:

Functionality	TD Mobile Pay app	Card Reader	Merchant Portal
Financial Transactions			
Sales	Yes	-	-
Discounts	Yes	-	-
Refunds	Yes	-	Yes
Voids	Yes	-	Yes
Review Sales	Yes	-	Yes
Process Payments	-	Yes	-
Product Catalog			
Add Products	Yes	-	-
Add Categories	Yes	-	-
Receipts			
Resend	Yes	-	Yes
Download		-	Yes
Customization	Yes	-	Yes
Bonding	Yes	Yes	-
Security			
Change MFA Method	Yes	-	Yes
Change Password	Yes	-	Yes
Update Account Profile	Yes	-	Yes
Reports and Statements	-	-	Yes
Manage Staff	-	-	Yes
Manage Taxes	Yes	-	-
Manage Card Readers	Yes	-	Yes

The card reader

The card reader allows the customer to enter financial transaction information. Refer to the diagram to the right to familiarize yourself with the terminal layout.

1. Power key

Press to power the terminal on.

Press and hold for 3 seconds to power the terminal off.

2. Command keys

In order left to right, **Cancel**, **Correction**, and **OK** / **Enter**.

3. Card readers

- a) Swipe cards
- b) Insert chipped cards
- c) Contactless cards

Screens

There are two main screens that you will use to navigate the card reader. They are the:

- Idle screen
- Menu screen

Idle screen

The default screen is called the Idle screen. It displays important information and icons. They are:

1. Bluetooth icon

You will see the Bluetooth icon on this bar will be different depending on which setup or comms method is chosen.

The grey icon indicates that Bluetooth is not connected to the TD Mobile Pay app.

The orange icon indicates that the card reader is connecting to the TD Mobile Pay app.

The green icon indicates that the card reader is connected to the TD Mobile Pay app.


2. Power

The battery icon in the top-right corner indicates the terminal battery level. When the charging plug icon appears in the top-right it means it is charging.

3. Menu

Press this to open the **Menu** screen.





Menu screen

The screen is displays the following icons: **Settings**, **Device Info**, and **Service**.

Settings


The Settings menu contains the *BLE (Bluetooth) Configuration* and the card reader *Speaker Volume*menus. To access the Settings screen you will need to
enter a four-digit passcode. This passcode is the last
numbers of the Device ID on the back of the card
reader and begins with LW.

Device Info

The Device Info screen displays the card reader information such as **Terminal ID** and **Serial Number**.

Service

The Service screen is only used by TD Merchant Solutions Technicians.



TD Mobile Pay application


There are three main screens that you will frequently use to navigate the mobile application. They are the:

- New Sale screen,
- · Connection Manager screen, and
- Menu screen.

New Sale screen

The New Sale screen is the default screen once you log into the TD Mobile Pay app. From here you can do the following:


Icon	Description
Menu	This icon accesses the Menu screen where you can access: New Sale, Dashboard, Product Catalog, Card Readers, Sales History, and Settings.
Search	This icon is only used if you have created a product catalog. If you have, you can search for an existing product.
Cart	This icon displays whether there is an existing sale in progress with a number indicating the amount of items. If you press this icon you can access the existing sale and submit it for payment.
Quick Sale	This icon allows you to perform a sale with out using items in the product catalog.
New Product	This icon allows you to quickly add a new product to your product catalog. It will no longer appear once you create your first product. You must then use the Product Catalog option to add products.



Connection Manager screen

The Connection Manager screen is where you can review, find, and connect the TD Mobile Pay app to a card reader. From here you will see the following:

Icon / Button	Description
Menu	This icon accesses the Menu screen where you can access: New Sale, Dashboard, Product Catalog, Card Readers, Sales History, and Settings.
New Sale	This icon will take you to the New Sale screen.
Scan	Press this button to search for nearby active card readers to connect the TD Mobile Pay app to.
Bonded Devices	This section displays which card reader is currently connected to the TD Mobile Pay app. The bonded device must have green checkmark to be able to process transactions.
Available Devices	This section displays all the card readers that are available to be connected to the TD Mobile Pay app. If you don't have a bonded device you will see the option to start the Card Reader Wizard in this section.




Menu screen

The Menu screen is where you access configuration and information on your solution.

In the top-left corner you will see the application status and indicates whether the TD Mobile Pay app is connected to a card reader (Ready for use) or is not connected (Action Required).

From this menu you can access the following:

Icon	Description
Connection Manager	This is the gear icon in the top-right corner of the screen and it will take you to the Connection Manager screen to connect a card reader to the TD Mobile Pay app.
New Sale	This will take you to the New Sale screen.
Dashboard	This will take you to the Dashboard screen to show high level sales information for your business.
Product Catalog	This will allow you to add, edit, or remove items and categories from your Product Catalog.
Card Readers	This will take you to the Card Readers screen and allow you to view your card reader status.
Sales History	This will take you to the Sales History screen to show detailed sales information for your business.
Support	This displays contact information and a link to the Troubleshooting Wizard to help you connect your card reader to the TD Mobile Pay app.
Settings	This is the gear icon in the bottom-left corner of the screen and will take you to the Settings screen where you can access and change your personal profile, view your business profile, and modify the receipt message.




Merchant Portal

The Merchant Portal is an online website that allows you to monitor and update your account, to view reports and analytics, and track your sales. The information is arranged into the following tabs:

- Dashboard a quick overview of current and historical transactions
- Sales History a detailed view of transactions
- Reports three reports (Detailed Transactions, Product Sales, and Tax)
- Monthly Statements access your available historical monthly statements
- Card Readers a list of the terminals used by your business
- Staff add, edit, and delete user IDs for your business
- Settings view and edit your login profile, view your business profile, and edit the custom message on your receipt

To access the Merchant Portal go to https://www.mobilepay.td.com/MerchantPortal/.



Financial transactions


All financial transactions must be initiated from the TD Mobile Pay application and payment must be received via the card reader.

New Sale

Before starting a sale ensure that your card reader:

- is active. Press the **Power** key to wake up your card reader.
- status in the top-left corner reads **Ready for Use** and there is there is a green checkmark on the **card reader** icon.

There are two ways to perform a sale. They are **Select Product** or **Quick Sale**.



Select Product

You would perform this when you have already entered the product on the application so that it can be selected from a list of available products on the catalog.

Quick Sale

You would perform this when the product cannot be selected from a list of available products on the catalog.

Select product

- 1. On the TD Mobile app: Go to the **New Sale** Screen.
- 2. Select the **product** for purchase and the **Add to Cart** screen appears.
- 3. Enter the quantity for sale by pressing the +/- buttons or manually entering in the quantity.
- 4. Press the **checkmark** in the top-right corner of the screen to add the item to the cart.
- 5. Repeat steps 2 and 4 to select more products. When finished go to Step 6.
- **6.** Press the **Cart** icon in the top-right corner of the screen.

You can make changes to the sale here before submitting the products for payment. Swipe the product to the left to access the **Edit** and **Delete** buttons.

7. Go to New Sale - Payment.

Quick Sale

- 1. On the TD Mobile app: Go to the **New Sale** Screen.
- 2. Select Quick Sale.
- **3.** Enter a product or service name.
- **4.** Specify a price for the product or service.
- **5.** Select the appropriate taxes.
 - a) Choose the applicable tax or taxes. (See *Managing Taxes* to define what taxes are available on this screen.)

For example, if you'd like to sell something for a total of \$10.00 with tax included, but don't want to calculate what the base price is, the app can do it for you. You can enter \$10, check **Tax Included in Price**, choose the applicable tax and the app will calculate the base price and it will show it on the **Cart** screen.

- b) You can select **Tax Included in Price** if you'd like the tax to be included in the price.
- c) Press Confirm.
- **6.** Enter **Quantity**.
- 7. Select the checkmark in the top-right corner of the screen to add the item to the cart. Repeat steps 2-7 to add any additional products to the cart. When finished go to Step 8.
- 8. Press the **Cart** icon in the top-right corner of the screen.

You can make changes to the sale here before submitting the products for payment. Swipe the product to the left to access the **Edit** and **Delete** buttons.

9. Go to New Sale - Payment.

New Sale - Payment

1. On the TD Mobile app: Select the payment method for your sale: (Debit/Credit or Cash).

Debit/Credit

Selecting Debit/Credit will allow you to accept a Debit or Credit payment by having a customer **Insert** / **Tap / Swipe** their card or **Tap** their digital wallet.

If tips are enabled on your card reader, the customer will be prompted to optionally enter a tip (percentage or dollar amount) before presenting their card.

Cash

Selecting **Cash** will allow you to record your payment. You will be responsible for collecting cash and dispensing the correct change. The screen allows you to type in the amount tendered by the customer and it will display the change due.

The application offers four pre-populated **quick amounts**. If the customer happens to give one of these four quick amounts, you can press the appropriate.

2. A summary page will display. From here you can choose to send a receipt to the customer via email and/or a mobile number or complete the transaction without sending a receipt.

Discounts

You can apply a discount to all or a selection of items for purchase. The TD Mobile Pay app supports percentage (%) and dollar amount (\$) based discounts.

Add a discount:

- 1. On the TD Mobile app: Select your **item(s) for sale** and press **Cart**.
- 2. Press ADD next to discount.
- 3. Press the checkbox next to the item(s) that you want to discount. All quantities for the selected item(s) will be discounted.
- 4. Press Next.
- 5. Select the discount option: Amount (\$) or Percentage (%).
- **6.** Enter the discount amount and press **Apply**.

Discounts entered as a dollar amount will be applied across all selected products based on a unit price. For example if you selected 2 items of \$50 and \$100 each. Applying a \$9 discount would result in the first item being discounted \$3 and the second item being discounted \$6.

7. If you are happy with the discounted amount, go to **New Sale - Payment**. If you entered a discount in error, go to **Edit a discount** below.

Edit a discount:

- 1. On the TD Mobile app: Go to the **Cart** screen.
- 2. Press **Edit** next to discount from the cart screen.
- 3. Press the checkbox next to the item(s) that you want to discount. All quantities for the selected item(s) will be discounted.
- 4. Press Next.
- 5. Select the discount option: Amount (\$) or Percentage (%).
- 6. Update the discount amount and press **Apply** to apply the new discount.

Voids and refunds

You can manage voids and refunds within the TD Mobile Pay app by accessing your Sales History. Find the specific transaction and view your options below.

You will not see a void option if:

- a partial refund has already been performed on the transaction OR
- the transaction was performed on a prior day and has been submitted for settlement.

Voids

You would void a transaction that was performed on the current day. When you void a transaction **all monies** (sale amount, tips and taxes) will be returned to the customer; there are no partial voids. To perform a void:

- 1. On the TD Mobile app: Press **Menu** → Sales History.
 - On the Merchant Portal: Click Sales History.
- 2. Select the transaction to be voided.
- 3. Press Void.
- 4. Review the summary and press Void.
- 5. Follow the on-screen prompts based on the payment method available for void.

Refunds

You would refund a transaction if a partial amount is required or if the transaction took place on a prior day. Refunds should always be performed to the same payment method and card number whenever possible. To perform a refund:

- 1. On the TD Mobile app: Press **Menu** → Sales History.
 - On the Merchant Portal: Click **Sales History**.
- 2. Select the transaction to be refunded.
- 3. Press the **Refund** button.
- **4.** Select the items for refund by pressing the **+/-** buttons next to the appropriate products. The tip can also be selected for refund by selecting the **Refund Tip** checkbox. By default it is not selected.
- 5. Once all items are added, tap the Subtotal button to go to the Refund Summary screen.
- **6.** Review your selections and tap the **Refund** button.
- 7. Follow the on-screen prompts based on the payment method available for refund.

Receipts

Receipt example

Each transaction has a receipt and most of the information is purely for record keeping. There are some points of important information you need to be aware of to ensure that your transactions have completed correctly.

Order #: The order number associated with the transaction which is generated by the solution.

Transaction Type: This shows what type of transaction was done (Sale, Void, etc.).

Card Type: This shows what kind of card was used for the transaction (Interac, Visa, Mastercard, American Express). Cash transactions will not have this information.


Card Number: The masked number of the card used for the transaction. Cash transactions will not have this information.

Auth Number: The authorization number associated with the transaction. Cash transactions will not have this information.

Entry Method: This is how the card was used (contactless, chip, etc.). Cash transactions will not have this information.

Approved: Always ensure that debit and credit sales are approved before completing the transaction as it could be **Declined**.

Credit/Debit Receipt TRANSACTION RECORD TorontoMerchant 77 King St W Toronto, ON M5K1A2 (+1) 437-882-3466 20003871 Terminal ID: MPOSNBS00042 RRN: 001001445 Order #: 0000004422 2021/05/12 17:44:35 **SALE** 1 Items Product/Service \$0.98 \$0.98 x 1 Subtotal \$0.98 0.00 Tax Total \$0.98 Card Number: *********5041 Interac | Default Auth Number: 001675 B Entry Method: Contactless (001) Approved AID: A0000002771010 Application Label: Interac TVR: 8000008000 TSI: 2800 AROC: 2DC0CA71A27781AF D Payment services provided by TD



Resend a receipt

If a customer requests that you send them a receipt from a past transaction, you can resend the PDF receipt to a their email address or mobile number.

The receipt is attached when sending to an email address. A secure link is provided to download the receipt when sending to a mobile number.

To resend a receipt:

- 1. On the TD Mobile Pay app: Press **Menu** → Sales History.
 - On the Merchant Portal: Click Sales History.
- **2.** Select the **transaction**.
- 3. Select Send Receipt.
- 4. Enter the customer's email address and/or mobile number and click Send Receipt.

Download a receipt

If you wish to save a copy of a transaction receipt, you can download a PDF copy on the Sales Details screen. To download a receipt:

- 1. On the Merchant Portal: Click Sales History.
- 2. Select the transaction to view the details.
- 3. Click View Receipt to download the receipt.

Reviewing sales

With TD Mobile Pay, you can track daily sales statistics performed by you or your staff.

The **Dashboard** provides a real-time summary of your sales, including total sales, refunds, taxes and tips. You can view the information by payment type or by the staff member that conducted the transaction.

The **Sales History** allows you to review a list of your previous sales. You may click on the row of a transaction to see more detail and resend a receipt. When you need to find a specific transaction, you are able to browse by payment type, date range or staff member that conducted that transaction.

Need to find a past transaction? You can track your historical transactions from the past 18 months.

Dashboard

To view the Dashboard:

- 1. On the TD Mobile Pay app: Press **Menu** → Dashboard.
 - On the Merchant Portal: Click Dashboard.
- 2. The following information will be displayed for the specified specified date range.
 - **Total Sales:** This is the total sales dollar figure that your business has transacted in the last month. It will also display the percentage change over the selected time periods.
 - **Number of Sales:** This is the total number of sales that your business has transacted in the last month. It will also display the change over the selected time periods.
 - **Total Refunds:** This is the total refund dollar figure that your business has transacted in the last month. It will also display the change over the selected time periods.

- **Number of Refunds:** This is the total number of refunds that your business has transacted in the last month. It will also display the change over the selected time periods.
- **Total Tips:** This is the total tip dollar figure that your business has collected in the last month. It will also display the change over the selected time.
- **Total Tax Collected:** This is the total tax dollar figure that your business has collected in the last month. It will also display the change over the selected time periods.
- Last Transaction: This is the time stamp of the last transaction that your business has performed. This information will not change until a new transaction takes place. It will not change by selecting a new filter.
- 3. You can filter your results by selecting them from the drop down menus on the Merchant Portal or by pressing the **Filter** icon in the bottom-right corner of the TD Mobile Pay app. The following filters can be applied:
 - User View: All Users/Business (default) or an Individual.
 - Payment Method: Credit, Debit or Cash.
 - **Date Range:** Today, Yesterday, Last 7 Days, Last 30 Days, This Month, Last Month, or Custom Range. Whatever date range you select, it will compare your current transactions against historical transactions of the same time range. For example, if your date range is Last 7 Days, then it will use the 7 Days prior for comparison.
- 4. Click Apply / Apply Filters.

Sales history

To view the Sales History:

- 1. On the TD Mobile Pay app: Press **Menu** → Sales History.
 - On the Merchant Portal: Click Sales History.
- 2. The following information will be displayed for each transaciton that took place between specified date range.
 - **Date:** This is the transaction date.
 - **Time:** This is the time that the transaction took place.
 - Order Number: This is the invoice number.
 - **Items Sold:** This is the number of items in the transaction.
 - **Users:** This is the user who performed the transaction.
 - **Transaction Type:** This is the type of transaction performed. There are three possibilities: Sale, Refund, Void.
 - **Payment Type:** This is the payment type used to pay for the transaction. There are three possibilities: Credit, Debit, or Cash.
 - **Card Type:** This is the type of card used to pay for the transaction. The possibilities are: Visa, MC, AE, and Interac.
 - **Total:** This is the total amount of the transaction including tax and tip.
 - **Status:** This is the status of the transaction. There are three possibilities: **Approved**, Declined, or Not Completed.
- 3. You can filter your results by selecting them from the drop down menus on the Merchant Portal or by pressing the Filter icon in the bottom-right corner of the TD Mobile Pay app. The following filters can be applied:
 - User View: All Users/Business (default) or an Individual.
 - Payment Method: Credit, Debit or Cash.

- **Date Range:** Today, Yesterday, Last 7 Days, Last 30 Days, This Month, Last Month, or Custom Range. Whatever date range you select, it will compare your current transactions against historical transactions of the same time range. For example, if your date range is Last 7 Days, then it will use the 7 Days prior for comparison.
- 4. Click Apply / Apply Filters.

Settlement

The TD Mobile Pay solution automatically performs a daily settlement each night at 23:59 EST.

A settlement must be performed on each terminal in order to maintain accurate records and balance your accounts. This is important as it closes all open batches and starts a new batch on the terminal.

Configuration

Manage your product catalog

You can manage your commonly sold products and services within TD Mobile Pay app by accessing your Product Catalog.

- If your business has staff users, they will be able to access and sell products from your catalog but will not be able to make changes to it.
- The products in the catalog are sorted by name in alphabetical order. If you are having trouble finding a product, you can press the search [magnifying glass ICON] icon to reveal the search bar.

Add a new product

To add a new product:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press the + button. Refer to the following sections below for more details:

Applying a Tax

You can add a tax to your new product. You are responsible for all required taxes to be applied to your products or services.

- a) Select the product or service you would like to apply tax to.
- b) Select **Applicable Tax** to display a list of taxes pre-configured for your business. See **Managing Taxes** for more information.
- c) Select the applicable tax(es) and tap Done.

It is your responsibility to ensure that the correct tax is charged for your products and services.

Assigning a Product to Categories

To help organize your catalog, you can assign products to categories.

- a) Select the product or service you would like to assign a category to.
- b) Select **Categories** to display a list of categories configured for your merchant account. See *Managing Categories* for more information.
- c) Select the applicable categories, and press **Save** to apply it to the product.

Adding an Image

You can add an image to your new product. The image will appear in your Product Catalog.

- a) Select the product or service you would like to add an image to.
- **b)** Press the **Price Tag** icon or the current product image. You will see 2 options:

Capture Image: Use your mobile device's camera to take a picture of the product.

Choose Image: Select an image from the gallery on your mobile device.

Note: Remove Image will be displayed, only if an image is present.

3. Once you have defined the values for your product press **Save**. Your product is now saved to your Product Catalog.

Disable or enable a product

You can disable/enable a product to remove it from the catalog when performing a catalog sale. This allows you to re-enable it in the future for things like seasonal products or when you have run out of the product in question. To disable/enable a product:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Swipe the product to the left.
- 3. Press Disable/Enable.

Delete a product

You can delete a product to permanently remove it from the catalog. To delete a product:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press or swipe the product to the left.
- 3. Press Delete.
- **4.** Press **Delete** again to confirm.

Manage your product categories

Categories allow you to organize your catalog more efficiently. For example, if your business sells clothing you could create categories like skirts, pants, socks, to better help you navigate the catalog when performing a sale. You can manage your categories from the Product Catalog page.

Add a category

You can add a new category to help group and organize your products. To add a category:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press +.
- 3. Enter a Category Name, choose the applicable product(s) and press Save.

Edit a Category

You can edit a category you have previously set up including the category name and products the category applies to. To edit a category:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Select a Category in the list to edit.

3. Update the Category Name or select the Associated Product(s) and press Save.

Category Name: This changes the category name.

Associated Product(s): This edits the products in this category. Note: Products can be in multiple categories.

Delete a category

Deleting a category is similar to deleting products. To delete a category:

- 1. On the TD Mobile Pay app: Press Menu → Product Catalog.
- 2. Swipe the **Category** to the left to reveal the **Delete** button.
- 3. Press Delete and press Delete again to confirm.

Manage your taxes

Add a tax

To add a tax to one or more products:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press the + button.
- 3. Press Add Tax.
- 4. Select the Tax label.
- 5. Enter the Tax Rate (%).
- **6.** Choose the **Associated Product(s)** and press **Save**. You do not have to assign the tax to any products, but this will make transactions go more quickly if this is preset and assigned to the products.

Edit a tax

To edit a tax you have previously set up including the type, percentage, and products the tax applies to:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press the **Taxes** tab.
- 3. Select an available tax.
- 4. Edit the Tax Label, Tax Rate, Enable/Disable the tax, or the Associated Product(s).
- 5. Press Save.

Disable a tax

To temporarily disable a tax:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- 2. Press the Taxes tab.
- 3. Swipe left on a Tax.
- 4. Press Disable. You can also go to the View Tax screen and Enable or Disable it.

Delete a tax

To permanently delete a tax:

- 1. On the TD Mobile Pay app: Press **Menu** → Product Catalog.
- **2.** Press the **Taxes** tab.
- **3.** Swipe left on a **Tax**.
- 4. Press Delete.
- 5. Press **Delete** to confirm. You can also go to the *View Tax* screen and press **Delete Tax**.

Customize your receipts

You may add a custom message to the bottom of your receipts for your customers. To create or edit your message:

It is your responsibility to ensure that the content you add to the receipt complies with all applicable laws. By using this feature, you agree that you are solely responsible for any messages displayed on the receipt.

- On the TD Mobile Pay app: Press Menu → Settings → Receipts.
 On the Merchant Portal: Click Settings → Receipt.
- 2. Enter your message. The receipt will automatically show a Receipt Preview to the right.
- 3. Click **Save** once you are satisfied with your message.

Manage your card readers

The card readers screen lists the card readers associated to your merchant account, including: Make, Model, Merchant ID associated with it, Terminal ID, Alias (user-friendly or descriptive name), Serial Number, Activation Date, Last Connection Date, and Status.

View a card reader

To view your card readers:

On the TD Mobile Pay app: Press Menu → card readers → Select a card reader to view.
 On the Merchant Portal: Click card readers → Select a card reader to view.

Connecting to your card reader

Once you have paired, activated and connected to your card reader for the first time, you will not need to pair or activate the card reader anymore. The following will explain how you can connect to your card reader in the future any time you log in.

Connecting Automatically

Once you log in to the app, if the card reader is powered on and connected to your mobile device via Bluetooth, the TD Mobile Pay app will automatically attempt to connect to the card reader.

In the menu and in the Connection Manager you will be able to see states transition from **Scanning** to **Connecting** to **Ready for Use**.

To view the card reader status:

- 1. Open the application menu. You can do this by swiping the application from the left edge of the screen to the right or by pressing the menu icon.
- 2. The status of the card reader can also be viewed in the Connection Manager. You can access the Connection Manager by pressing the cog wheel icon to the right of the status.

Connecting Manually

In case the card reader was not powered ON when you logged in, the app might not be able to automatically connect to your card reader. In this case, you'll need to manually connect.

To manually connect your Card Reader:

- 1. On the TD Mobile Pay app: Press Menu → Connection Manager.
- **2.** Press **Scan**. The app will start scanning.
- 3. Once the scan is complete you will be able to see all the card readers that are available for connection.
- **4.** Press the card reader you would like to connect to.
- **5.** Once the card reader has connected you will see a green check mark in the top right corner of the card reader you have selected. Now you're ready to process card transactions.

Edit a card reader's name (alias)

You can assign a user-friendly alias name to each card reader for easier identification on the Mobile App and Merchant Portal. To update a card reader's name:

- On the TD Mobile Pay app: Press Menu → card readers → Select a card reader.
 On the Merchant Portal: Click card readers → Select a card reader.
- 2. Click Edit for the desired card reader.
- 3. Enter the new Alias (Name) and click Save.

Reinitialize a card reader

If your card reader's Bluetooth connection to your mobile device is working but you are unable to perform transactions, you can try reinitializing your card reader. To reinitialize a card reader:

- 1. On the TD Mobile Pay app: Press **Menu** → Support.
- 2. Press Initialize Now.
- 3. The initialization process may take a few minutes. Once it is completed, you will see a confirmation screen. The card reader status will display **Ready for Use**.

Deactivate a card reader

- On the TD Mobile Pay app: Press Menu → card readers → Select a card reader.
 On the Merchant Portal: Click card readers → Select a card reader.
- 2. Press Deactivate.
- 3. Press Deactivate again to confirm. Once the card reader is deactivated, you cannot reactivate it.

Adjust a card reader's volume

To increase / decrease the volume on the card reader:

- 1. On the card reader: Press Menu \rightarrow Settings.
- 2. Enter your **Passcode**. The passcode is the last four digits of the serial number located on the back of the card reader (e.g. LW#####).
- 3. Press Speaker Volume.
- **4.** Press or + to adjust the card readers volume. Each press will decrease or increase the volume by 10%. Default setting is 50%.

Replace a card reader

Have a broken or damaged card reader? Call the TD Merchant Solutions Contact Centre at 1-800-363-1163.

Update your account profile

Change your account name

To change the name associated to your account, please call our TD Merchant Solutions Contact Centre at **1-800-363-1163**.

Change your language preference

The TD Mobile Pay app can be viewed in either English or French. To change your language:

- On the TD Mobile Pay app: Press Menu → Settings → Language from the menu button.
 On the Merchant Portal: Click Settings → Personal Profile.
- 2. Click Edit on Language Preference.
- 3. Select English or French.
- 4. Click Save.

Change your email

Your email address is used for authentication when signing in. To change your email address:

- On the TD Mobile Pay app: Press Menu → Settings → Personal Profile.
 On the Merchant Portal: Click Settings → Personal Profile.
- 2. Press Edit on your email address.
- 3. Enter your new email address and tap Save.
- 4. View the email sent to your new email address and click the Verify Email Address button within.

Change your mobile number

Your mobile number can be used for two-factor authentication when signing in. To change your mobile number:

- On the TD Mobile Pay app: Press Menu → Settings → Personal Profile.
 On the Merchant Portal: Click Settings → Personal Profile.
- 2. Click Edit on the phone number.
- 3. Enter your **new Phone Number** and click **Save**.

Security

Change your password

Your password is required to sign into the Mobile App and Merchant Portal. To change your password:

- On the TD Mobile Pay app: Press Menu → Settings → Personal Profile.
 On the Merchant Portal: Click Settings → Personal Profile.
- 2. Click Edit beside Password.
- 3. Enter your Current Password.

- **4.** Enter your **New Password**. The new password must contain the following:
 - 8 16 characters
 - at least 1 upper case character
 - at least 1 lower case character
 - at least 1 number
- 5. Confirm your **New Password** and click **Save**.

Change your authentication preference

Your Multi-Factor Authentication Preference (set up when you first signed in) is used as an additional security check when accessing the TD Mobile Pay app from different devices or after long periods of inactivity. It's also required if your password was incorrectly entered multiple times during sign in.

You can change your MFA preference whenever you wish to suit your needs.

To change your MFA / Multi-Factor Authorization preference:

- On the TD Mobile Pay app: Press Menu → Settings → Personal Profile → Edit MFA Preference.
 On the Merchant Portal: Click Settings → Personal Profile.
- 2. Press Edit beside MFA / Multi-Factor Authorization Preference.
- 3. Select either SMS or Authenticator App and then tap Save.

SMS

a) A verification code will be sent via text message to your mobile phone number.

Authenticator App

- a) Open your Google Authenticator app or Microsoft Authenticator app and manually enter the authentication key provided by the TD Mobile Pay into your Authenticator App to receive a verification code.
- **b)** Enter the 6-digit **verification code** generated by your Authenticator App and press **Submit** to finish the update.

View your business profile

To view and verify that your business information is correct, you can review your business profile:

- 1. On the TD Mobile Pay app: Press **Menu** → Settings → Business Profile.
 - On the Merchant Portal: Click **Settings** → Business Profile.

To change the name or address associated on your business profile, please call our TD Merchant Solutions Contact Centre at **1-800-363-1163**.

Manage your staff / users

There are three user levels:

- Business Owner
- Supervisor
- Employee

The Staff User feature allows you to have additional user accounts for your employees to use with their own card reader or share multiple devices.

Add a new staff user account

To add a new employees:

- 1. On the Merchant Portal: Click Staff.
- 2. Click Add Staff.
- **3.** Enter the following: **First Name**, **Last Name**, **Email**, **Mobile Phone Number**, **Language**, **Role** (Employee or Supervisor), and whether you want to give them **Refund Permission**.

Be cautious as to who you give **Refund Permission** to as it has the potential for fraud.

4. Click Save.

Your new staff will not be visible on your list of staff users until it is processed by a TDMS Support Representative. Once completed, an email will be sent to you and your newly added staff member to confirm the addition.

View your staff / user accounts

To view the list of your employees:

- 1. On the Merchant Portal: Click Staff.
- 2. You staff list will display with the following headings:
 - First Name
 - Last Name
 - Email (where any TD Mobile Pay communications will be sent such as password resets.)
 - Mobile Phone Number (where any SMS / Text authentications will be sent)
 - Role (Employee or Supervisor)
 - Status (Email Sent, Not Verified, Verified)
- 3. Click a specific staff member from the list to view their details.

Reports

You can download detailed analytics and reports for your business. These reports will allow you to accurately track your transactions, as well as products and services your business has sold. The reporting feature provides real-time reporting and analytics to track and analyze your sales.

Run a report

- 1. On the Merchant Portal: Click **Reports**.
- 2. Enter the **From** and **To** dates for the report date range for the report you want to generate (**Detailed Transactions**, **Product Sales**, or **Tax**).
- 3. Click **Generate** beside the desired report.
- **4.** Once generated, you can export the data for any the reports to PDF or Excel. Click either **Download CSV** (Excel) **Download PDF** to download the report in your desired format.

Navigation

Depending on time range selected for the report, the information will not fit on one page. To navigate to another page:

- 1. On the Merchant Portal: Click on the **arrows** in the top-left corner of the screen .
- 2. Click View to go to the selected page.

Report label

Once a report is created it will include a report label. This information is created on every report and located in the top-left corner of the report. It contains the following:

Report Labels	Description
Report Date	This is when the report was run.
Report Name	This is the report type. In this case, Detailed Transactions Report.
Run By	This is who initiated the report.
Business Name	This is your business name.
MID	This is your Merchant ID.

The report label appears on every report that you run.

Detailed transactions report

The Detailed Transactions Report provides a list of sales for a given time period. The report includes details of each transaction such as payment method, geolocation, taxes, tips and receipt delivery.

The report will display the following information:

Headings	Description
Date	This is the transaction date.
Time	This is the time that the transaction took place.
Order Number	This is the invoice number.
User	This is the user who performed the transaction.
Location	If your business has multiple locations, the specific location would be displayed here.
IP Address	The Mobile Phone address. (Unsure what this refers to – WiFi/BT terminals only?) Send to Nicole.
Terminal ID	This is the unique ID for your terminal.
Serial #	This is your terminal's serial number.
Mobile Device ID	This is the unique ID for the Mobile Phone used.
Transaction Type	This is the type of transaction performed. There are three possibilities: Sale , Refund , or Void .
Payment Method	This is the payment type used to pay for the transaction. There are three possibilities: Credit , Debit , or Cash .
Entry Method	This is how the card was used to in the transaction: Contactless , Chip , or Swipe).
Card Type	This is the type of card used to pay for the transaction. The possibilities are: Visa , MC , AE (American Express), and Interac .
Card Number	This is the credit or debit card number used in the transaction.
Auth #	This is the transaction authorization number.
Discount	This is the discount amount or percentage.
Subtotal:	This is the total amount before tax and tip have been added.
HST/GST/PST/QST	These are the tax amounts collected for the transactions.
Tip	This is the tip amount.
Total	This is the total amount of the transaction including tax and tip.
Receipt Sent	(Date of transaction? Yes or No or resent?) [TEST] Send to Nicole.
Recipient Email	This is the email address where the receipt was sent.
Recipient Mobile Number	This is the mobile phone number where the receipt was sent.
Status	This is the status of the transaction. There are three possibilities: Approved , Declined , or Not Completed .

At the bottom of the Detailed Transactions Report is a summary with the following information:

Summary Headings	
Transaction Amount Summary	This is the dollar value of Credit, Debit, and Cash transactions by transaction type (Sale, Refund, and Void) and overall Net Amount.
Transaction Quantity Summary	This is the number of Credit, Debit, and Cash transactions by transaction type (Sale, Refund, and Void) and overall Net Quantity.
Discount Amount Summary	This is the amount of Credit, Debit, and Cash discounts by transaction type (Sale, Refund, and Void) and overall Net Amount.
Discount Quantity Summary	This is the number of Credit, Debit, and Cash discounts by transaction type (Sale, Refund, and Void) and overall Net Quantity.
Tax Amount Summary	This is the tax dollar value of HST, GST, PST, and QST sorted by transaction type (Sale, Refund, and Void) and overall Net Amount.
Tax Quantity Summary	This is the number of HST, GST, PST, and QST tax transactions by transaction type (Sale, Refund, and Void) and overall Net Quantity.
Tip Amount Summary	This is the tip dollar value by transaction type (Sale, Refund, and Void) and overall Net Amount.

Product sales report

The Product Sales Report provides sales volume grouped by product for a given time period. The report will display the following information:

Headings	Description
Product Name	This is the name of the product sold.
Product Description	This is the brief description that you create when adding a product to your solution.
Product SKU	This is the product number (stock keeping unit) that you assign to a product when you add it to your solution.
Quantity Sold	This is the number of a specific product that have been sold.
Quantity Returned	This is the number of a specific product that have been returned.

Tax report

The Tax Report provides the sum of sales taxes collected for a given time period. The report includes taxable sales, refunds and the net tax collected. The report will display the following information:

Headings	Description
Tax Name	This is the tax amount collected and split into the following headings: HST, GST, PST, and QST.
Rate	This is the tax rate (percentage) charged.
Taxable Sales	This is the number of sales that collected tax.
Sales Tax Collected	This is the amount of tax that was collected.
Taxable Refunds:	This is the number of refunds that collected tax.
Tax Refunded	This is the amount of tax that was refunded.
Net Tax Collected	This is the net amount of tax that was collected. This is calculated by subtracting Sales Tax Collected from Tax Refunded.

Statements

View merchant statements

Need to find a past statement? The past 25 months of statements are available from the Merchant Portal.

Review your historical processing volumes and fees by clicking on the row of a particular statement to see more details.

Download a statement

If you wish to save a copy of a merchant statement, you can download a PDF copy on the Merchant Statement screen. To download a statement:

- 1. On the Merchant Portal: Click **Monthly Statements**.
- 2. Select the statement you would like to download.
- 3. Click on the **row** of the statement to view the details.
- **4.** Click **Download** to download the statement. To better understand your statement, please refer to our online Statement Reader help guide.

Troubleshooting

If you're unable to resolve the problem after performing the following steps, please call the TD Merchant Solutions Contact Centre at **1-800-363-1163**.

Signing in using SMS/text MFA

Q: When I'm trying to log in, I'm asked for a verification code, but I can't receive it because my phone number changed. What should I do?

A: Call the TD Merchant Solutions Contact Centre at 1-800-363-1163 and we will change your phone number for you.

Q: When I'm trying to log in, I'm asked for a verification code, but I can't receive it because I don't have access to my phone. What should I do?

A: Call the TD Merchant Solutions Contact Centre at 1-800-363-1163 and we will change your MFA preference to email.

Signing In using Authentication App

Q: When I'm trying to log in, I'm asked for a verification code, but I can't access it because I deleted my account in the authenticator app. What should I do?

A: Call the TD Merchant Solutions Contact Centre at **1-800-363-1163** to reset your MFA preference so you can set up a new account in your authenticator app.

Q: When I'm trying to log in, I'm asked for a verification code, but I can't access it because I deleted the authenticator app. What should I do?

A: Call the TD Merchant Solutions Contact Centre at **1-800-363-1163** to reset your MFA preference so you can set up a new authenticator app or you can choose to use SMS instead as your MFA preference.

Q: When I'm trying to log in, I'm asked for a verification code, but I can't access it because I don't have access to the device where the authenticator app is located. What should I do?

A: Contact the TD Merchant Solutions Contact Centre at **1-800-363-1163** to reset your MFA preference so you can choose to use SMS instead as you MFA preference.

Forgot Your Password

Q: I clicked on the Forgot Password link and entered my email, but I did not receive an email with the temporary code that I need to reset my password. What should I do?

A: Emails are often delivered to spam, junk or secondary inboxes without us noticing. If the email cannot be found within one of these folders, try Forgot Password again and make sure that you entered your email address correctly.

If you haven't completed your account setup, locate your Welcome email and follow the instructions to set your password. You need to complete your account setup before you're able to use the Forgot Password option. If you cannot find your Welcome email, call the TD Merchant Solutions Contact Centre at **1-800-363-1163** to resend you the Welcome email.

Connecting to your card reader

Q: I'm getting an *Unsupported location* error when trying to connect to the card reader or when I'm trying to process a transaction. What should I do?

A: You can only connect to your card reader and process transactions if you are in Canada. If you are in Canada and are still having this issue, you can try the following:

- 1. Confirm Location Services are turned **ON** and permissions are granted for the TD Mobile Pay app.
- 2. Confirm your time zone is accurate on your mobile device.
- 3. If you are using a VPN connection, make sure it's connecting through servers in Canada.
- **4.** If you are somewhere that might be difficult for your mobile device to locate you (e.g. in a basement), retry from a different location.
- 5. If you are close to the Canadian border, call the TD Merchant Solutions Contact Centre at 1-800-363-1163.

Q: I cannot pair to my card reader for the first time. What should I do?

A: Make sure that the card reader is in bonding mode while trying to pair.

Q: I'm trying to pair my card reader again, but it doesn't work. What should I do?

A: See Remove the card reader from your mobile phone on the next page. Make sure that you've removed the previous bonding from the card reader settings.

Accepting payment

Q: I received an error "Payments are only accepted within Canada." What does that mean?

A: This means that the mobile phone that you are using does not have its **Location Services** set to **Canada**. Please refer to your mobile phone's documentation and set your location as **Canada**.

Q: I tried to process a card transaction and it says that it's "In Progress". What does that mean?

A: The mobile app communicates with the card reader via Bluetooth and with our servers through the Internet to complete a transaction. If a message gets lost or interrupted due to issues in transit, you may see an *In Progress* status. Please go to the Sale History and wait a couple of minutes to see what the final state will be.

In many cases the result will be **Not Completed** which means the transaction failed and you can try to process another transaction. If it says **Approved**, the transaction completed successfully, and you do not need to retry.

What do I do if the card reader displays a security alert?

If your card reader displays the message **Security Alert**, it means that your terminal has been damaged and must be replaced. Call the TD Merchant Solutions Contact Centre immediately at **1-800-363-1163**.

Why isn't my card reader powering on?

- 1. Plug the charging cord into the card reader and wait one minute until powering it on.
- 2. If this fails to power it on, call the TD Merchant Solutions Contact Centre at 1-800-363-1163.

What problems can I easily resolve?

Problem	Action	Required
Chip cards cannot be processed	1.	Follow the instructions on screen.
	2.	Try inserting a different card. If this card can be read, the problem is with the first card.
	3.	Use a cleaning card to clean the card reader.
Display is too bright or too dark	1.	Call the TD Merchant Solutions Contact Centre at 1-800-363-1163 .
Magnetic stripe card reader won't read cards	1.	Try swiping the card more quickly or more slowly.
	2.	Request another form of payment. If this card can be read, the problem is with the first card.
	3.	Use a cleaning card to clean the problem card reader.

Why isn't my card reader connecting to the application?

- 1. Confirm **Bluetooth** is **enabled** and permissions are granted for the TD Mobile Pay app.
- 2. Confirm Location Services are enabled and permissions are granted for the TD Mobile Pay app.
- 3. Close and relaunch the TD Mobile Pay app.
- 4. Restart your mobile device and card reader before attempting to connect again.

 If you are having issues with connecting your card reader, you can remove the pairing from your mobile phone and card reader before attempting to setup the connection again. Perform both of the following to completely remove the connection between your card reader and your mobile phone.

Remove the card reader from your mobile phone (Android)

- 1. Press **Settings** on your mobile phone.
- 2. Press Bluetooth and tap the cog wheel icon on the right of the card reader you would like to forget.
- 3. Press **Unpair** and confirm that you would like to forget this card reader.

Remove the card reader from your mobile phone (iOS)

- 1. Press **Settings** on your mobile phone.
- 2. Press Bluetooth and tap the cog wheel icon on the right of the card reader you would like to forget.
- 3. Press **Unpair** and confirm that you would like to forget this card reader.

Remove the mobile phone app from the card reader

- 1. Press Menu on the card reader.
- 2. Press BLE Configuration.
- 3. Press Remove Bonding.

Reference

Storing the card reader

- It must be stored in temperatures between 0° and 50° Celsius.
- Do not leave it outdoors overnight, especially in the winter.

Maintaining the card reader

- Don't place the card reader on a magnetized pad this will cause them to malfunction.
- Routinely clean it with a damp cloth so that any spills don't get into the inner workings.
- Use TD-approved cleaning cards for the chip and magnetic card readers.

Lost or stolen equipment

If your device has been lost or stolen, please:

- 1. Deactivate your card reader via the TD Mobile Pay app or the Merchant Portal. (lost or stolen)
- 2. Call the TD Merchant Solutions Contact Centre immediately at **1-800-363-1163** to report the incident. (lost or stolen)
- 3. Contact the police to file a report. (stolen only)

What should I do when the police arrive regarding the stolen device?

If a police officer arrives on site please record the following:

- Officer's name
- Officer's jurisdiction
- Officer's contact information
- Stolen device's serial number

The officer should provide you with a **report number**. After obtaining the above from the officer, please call the TD Merchant Solutions Contact Centre and provide this information so that you can receive a replacement device. See below for an easy to use information card to record the required information.

Police information

Name:	
PH #:	
FAX #:	

Contact Information

Please call the TD Merchant Solutions Contact Centre at **1-800-363-1163**. We would be happy to answer any questions you may have.

Authorization:

24 hours a day, seven days a week

Terminal Inquiries:

24 hours a day, seven days a week

General Merchant Inquiries:

Monday - Friday, 8 a.m. - 8 p.m. ET

Merchant Portal

To access your the Merchant Portal go to https://www.mobilepay.td.com/MerchantPortal/

Documentation Portal

This guide covers the most commonly used information in order to get you started. Your solution has more features and functionality to explore on our documentation portal which you can find at www.tdmerchantsolutions.com/posresources.

Below is a list of the available TD Mobile Pay documentation:

- Installation Guide
- Merchant Guide

