TD iWL252 / 255

Quick Start Guide



For the:

- TD iWL252 (Bluetooth)
- TD iWL255 (3G Wireless)



COPYRIGHT® 2016 by The Toronto-Dominion Bank

This publication is confidential and proprietary to The Toronto-Dominion Bank and is intended solely for the use of Merchant customers of TD Merchant Solutions. This publication may not be reproduced or distributed, in whole or in part, for any other purpose without the written permission of an authorized representative of The Toronto-Dominion Bank.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TD is under license. Other trademarks and trade names are those of their respective owners.

NOTICE

The Toronto-Dominion Bank reserves the right to make changes to specifications at any time and without notice. The Toronto-Dominion Bank assumes no responsibility for the use by the Merchant customers of the information furnished in this publication, including without limitation for infringements of intellectual property rights or other rights of third parties resulting from its use.

		`
	MERCHANT INFORMATION	
	Merchant Name	
	Merchant Number	
Ĺ		

Contents

About this Guide	1
Welcome kit contents	1
The TD iWL252 / 255 Solution	1
The terminals	
Default shortcut keys	
Accessibility features	
Changing the paper roll	
Screens(TD 74//050)	3
Idle screen (TD iWL252)	
Main menu screen	
Admin menu screen	
The Bluetooth Base	
Ports	
Communication options	
Cardholder Privacy and Security	
Terminal security	
Fraud prevention	
Manually entered credit card numbers Call for authorization	
Call for dutiforization	/
Financial Transactions	7
Accepted card types	
PINpad transactions	
Sale (credit card)	
Sale (debit card)	
Sale (phone or mail)	
Force post (sale or phone / mail)	
Void	
Transaction recall	
Return	
Receipts	
Receipt examples	
Business Day Functions	16
Performing a day close	16
Configuration	17
Configuration	
Changing the terminal communication method (TD iWL252)	
More features and functionality	17

Reporting	18
Business day reports	
Batch reports	
Customized reports	
EMV reports	
Troubleshooting	20
What problems can I easily resolve?	
Why don't I see a connection icon on the Idle screen?	
What is the signal strength?	
What can interfere with Bluetooth connectivity?	22
What can interfere with 3G connectivity?	22
Why isn't my terminal charging?	22
What do I do if there's a power outage?	
Reference	24
Maintaining the terminal	
Storing the terminal	
Entering letters and special characters	

About this Guide

This Guide provides an introduction to your TD iWL252 / 255 solution, hardware functionality, performing financial transactions, administration features and troubleshooting. For further information regarding its use and available features, please review our online documentation at www.tdmerchantsolutions.com/posresources.

Welcome kit contents

We are pleased to provide Merchants new to TD Merchant Solutions with the included Welcome Kit from. The enclosed information was prepared with you in mind, and includes the following:

- Paper rolls for the terminal
- Cleaning card and instructions
- Card acceptance decals (Visa®, MasterCard®, Discover®, American Express®, Interac® Direct Payment, etc.)
- Information to help you protect your business and customers from fraud

The TD iWL252 / 255 Solution

The terminal is solely for you, the Merchant. You will use the terminal to initiate transactions for customer's using credit or debit cards. Depending on your settings, some card types may not be accepted by your terminal.

The two terminals look virtually identical and have very similar functionality. There is an easy way to determine which one you are using.

TD iWL252 and Bluetooth® base

This terminal is the short range wireless version. It connects wirelessly to the Bluetooth charging base.





TD iWL255

This terminal is the long range wireless version. It connects to the mobile phone network.



The terminals

1. Paper chamber flap

2. Function keys

The /F1 and /F4 keys can be used as shortcuts and to select onscreen options. See below for more information.

3. Navigation keys

Use the arrow keys to navigate the screens and menus.

4. Command keys

Cancel

/ Correction or Paper advance

OK and shortcut to the *Main Menu* screen.

5. Card readers

- a) Insert chipped cards
- **b)** Swipe cards
- c) Contactless cards



Default shortcut keys

To access a specific menu or function, use the following shortcuts:

Transaction	Key
Sale (default)	- / F1
Pre-Auth Initiation (default)	► / F2
Navigation / scroll key	
Pre-Auth Completion (default)	F3 / F3
Phone / Mail Sale (default)	■ / F 4
Main Menu	OK / OK
Admin Menu	#* / Admin
Reprint last receipt	0 / O
Advance paper	/ Correction

Accessibility features

The TD iWL252/255 has numerous accessibility features which reflect TD's commitment to our customers. It has such features as:

- An adjustable key stroke sound when a key is pressed
- An adjustable screen brightness to create visual contrast
- A raised identifier on the:
 - **5** key,
 - Cancel key,
 - Correction key, and
 - OK key

Changing the paper roll

- **1.** Gently pull up on the **paper chamber panel** along the top of terminal and remove the old paper roll.
- 2. Unwrap a new paper roll and place it in the paper chamber so that the loose end of the paper feeds up from under the paper roll towards you.
- 3. Press down on the panel until it clicks shut and ensure there is a enough paper sticking out from the chamber that it touches the top of the terminal screen.
- **4.** Press **Correction** to advance the paper to ensure it is loaded properly.

Screens

Idle screen (TD iWL252)

The default screen is called the *Idle* screen. On it there are numerous important icons. They are, left to right:

1. Lock (security)

The lock icon will be closed or open. If the lock is open, do not use this terminal and contact the TD Merchant Solutions Help Desk to report it has been tampered with.

2. Bluetooth connection icons

The terminal's Bluetooth connection is indicated by a group of icons:

B Terminal is connected to the Bluetooth base but not responding.



- R Terminal is searching for connection.
- R Terminal is connected to the Bluetooth base.
- Indicates the terminal Bluetooth signal strength.

The number under these icons is the associated Bluetooth base serial number.

Indicates whether the terminal is connected to the network. It will be one of two colours: green (connected) or white (disconnected).

3. Power

The battery icon in the top-right corner indicates that the terminal battery level. When the lightning bolt appears on top of the battery, it means it is charging.

Idle screen (TD iWL255)

The default screen is called the *Idle* screen. On it there are numerous important icons. They are, left to right:

1. Wireless connection icons
The terminal's wireless connection
is indicated by a group of icons:



Indicates the terminal 3G wireless signal strength.

(((-))) Indicates whether the terminal is connected to the 3G wireless network. It will be one of two colours: green (connected) or grey (disconnected).



Lock (security)

The lock icon will be closed or open. If the lock is open, do not use this terminal and contact the TD Merchant Solutions Help Desk to report that it has been tampered with.


2. Power

The battery icon in the top-right corner indicates that the terminal battery level. When the lightning bolt appears on top of the battery, it means it is charging.

Main menu screen

From the *Idle* screen, press **OK** and the *Main Menu* screen appears. The *Main Menu* screen displays the following transactions:

- Return
- Void
- Force Post
- Phone / Mail Sale



Admin menu screen

From the *Idle* screen, press **Admin** key and the **Admin Menu** screen appears. It displays the following options:

- Logon / Logoff
- Business Day Menu
- Trans Recall Menu
- Setup Menu
- Reprint Menu
- Maintenance
- Other Functions



The Bluetooth Base

The Bluetooth base is only used with the TD iWL252. It acts as a connection to the payment network and as a short range wireless base for your TD iWL252 terminal. This base also acts as a charging station for the terminal.

Ports

The base has four ports on the back but you are only using the network adapter port and the power port:

- 1. Ethernet port
- 2. Power port



If you use a dial up connection, there is a panel on the bottom of the base that you can open and plug your phone line into.

Communication options

The TD iWL252 solution offers two options for communications: dial-up or Ethernet. You can set this however you wish to suit your existing place of business' setup.

If you want to change the security level of your terminal, please contact TD Merchant Solutions Help Desk at **1-800-363-1163**.

Cardholder Privacy and Security

Please refer to the **Cardholder Privacy** sheet in your Merchant welcome kit. It contains important information about your responsibilities to your customers and their personal and transaction information.

Terminal security

It is the Merchant's responsibility to secure the terminal, any user IDs or passwords and to prevent unauthorized use. In any event the Merchant will be liable for any unauthorized use of the terminal or any user IDs or passwords. There are three user security settings:

- No security (Default)
 No access restriction to the terminal functionality listed below.
- Medium Security
 Access is restricted to certain features by a supervisor or manager ID and password.
- High Security
 Access is restricted to certain features by a manager ID and password.

The following functions can be individually protected:

- End of Day
- Manual Account #
- Batch Reports
- B.Day reports
- Customized Reports
- Batch Close
- Recent Error Report

Fraud prevention

Please refer to the *How to Help Prevent Fraud* pamphlet in your Merchant welcome kit. You can also reduce fraudulent transactions on your terminal by enabling:

Manually entered credit card numbers

This is the ability to manually enter a credit card number into the terminal for a purchase transaction when a customer is performing a *card-not-present* purchase.

Transaction type	Default settings	
Manually entering a credit card number on the terminal	Protected by supervisor ID and	
This is the ability to manually enter a credit card number into the terminal for a purchase transaction when a customer is performing a card-present purchase.	password	
Mail order / Telephone order purchase	Disabled	
This is the ability to manually enter a credit card number into the terminal for a purchase transaction when a customer is performing a <i>card-not-present</i> purchase.		
Force post purchase	Disabled	
This is the ability to perform a transaction with a manually entered authorization number versus the transaction being authorized automatically through the terminal.		

Call for authorization

You can enable/disable call for authorization transactions.

We understand that the default settings that come with this terminal may not fully meet your businesses' needs. Should you wish to amend these default settings, please contact the TD Merchant Solutions Help Desk at **1-800-363-1163** to learn about your options.

Financial Transactions

The terminals can perform the following transactions:

- Sale (purchase)
- Phone / Mail sale
- Force post
- Return (refund)
- Void
- Partial authorization
- Pre-authorization*

^{*} These optional transactions and others, such as cashback and tips, are covered in our online documentation at www.tdmerchantsolutions.com/posresources.

Accepted card types

Your terminal(s) will accept whatever cards you indicated when you signed your contract with TD Merchant Solutions. If you wish to adjust your accepted card list, please call the TD Merchant Solutions Help Desk at **1-800-363-1163**.

PINpad transactions

When a PINpad is connected to the terminal the customer will use it exclusively to enter and information and make selections. For the transactions in this document we show the customer PINpad key options. If you only have a terminal, the customer will also use the terminal to enter information.

- Depending on your security settings, you may be required to enter a supervisor ID and password to proceed with any transaction.
- Press **0** on the terminal to reprint the most recent customer receipt.
- If the receipt has a signature line on it, the customer **must** sign it.

Sale (credit card)

- **1.** Press **F1**.
- 2. Enter the total dollar amount for the sale and press OK.
- 3. If you have tips enabled you will see the following steps.

Tip (optional)

- a) Customer confirms the dollar amount and presses Yes or No.
- b) Customer enters/selects the tip amount/option and presses OK.
- c) Customer confirms the dollar amount and presses Accept or Change.
- Perform one of the following payment methods: Insert, Swipe, Contactless or Manual Entry.

Contactless

a) The customer taps their contactless-enabled credit card on the contactless card reader.

The customer may be required to **swipe** or **insert** their card in some cases.

- **b)** Ask the customer if they would like a receipt: **Yes** or **No**.
- **c)** The screen shows that authorization number, the transaction total and the receipts print if requested.

Insert card

- a) The customer inserts their credit card.
- b) The customer enters their PIN and presses OK.
- **c)** The screen shows that authorization number, the transaction total and the receipts print.

Swipe card

- a) The customer swipes their credit card.
- b) Verify the card info with what is on the terminal screen and press **OK**.
- c) The screen shows that authorization number, the transaction total and the receipts print. The customer **must** sign the signature field on the merchant copy.

Manually enter card

- a) Enter the account number and press OK.
- b) Enter the expiry date and press OK.
- c) A manual imprint of the credit card is required. Make the imprint and press **OK**.
- d) Enter the three or four-digit **CVD number** and press **OK**. This number is generally located on the back of the credit card. This is can be an optional step depending on your settings.
- e) Indicate if the card was present for the transaction: **Yes** or **No**. The customer **must** sign the signature field on the merchant copy.
- **5.** If the payment type used has insufficient funds to pay the entire sale amount you may see the following:

Partial authorization (optional)

- a) The receipt will print showing how much was applied to the sale.
- **b)** The screen shows a balance owed.
- c) The customer decides the how they will pay the balance (Cash or Card).
 If the customer selects card, follow the appropriate steps for the selected card type: credit or debit.

If the customer selects cash the transaction will end. Ensure that you receive the correct cash amount for the balance of the transaction.

6. The screen shows that authorization number, the transaction total and the receipts print.

If the cardholder signature field appears on the merchant copy of the receipt, the customer **must** sign it.

Sale (debit card)

- **1.** Press **F1**.
- 2. Enter the dollar amount and press OK.
- **3.** If you have tips enabled you will see the following steps.

Tip (optional)

- a) Customer confirms the dollar amount and presses Yes or No.
- b) Customer enters/selects the tip amount/option and presses OK.

- c) Customer confirms the dollar amount and presses Accept or Change.
- 4. Perform one of the following payment methods: Insert / Swipe or Contactless.

Contactless

a) The customer taps their contactless-enabled debit card.

The customer may be required to **swipe** or **insert** their card in some cases.

Ask the customer if they would like a receipt: **Yes** or **No**.

Insert / swipe card

- a) The customer selects the account to use: CHQ or SAV.
- b) The customer enters their PIN and presses OK.
- 5. If you have cashback enabled you will see the following steps.

Cashback (optional)

- a) Customer confirms if they want cashback or not: YES or NO.
- b) Customer enters / selects the cashback amount/option and presses OK.
- c) Customer confirms the new total amount: **Accept** or **Change**.
- **6.** The screen shows that authorization number, the transaction total and the receipts print.

If the cardholder signature field appears on the merchant copy of the receipt, the customer **must** sign it.

Sale (phone or mail)

- These instructions are used for sales where the card is **not** present. If the card is present at sale, see *Credit card sale*. If you use the incorrect sale transaction you could incur extra charges.
- There are risks performing transactions when the credit card is not present. Ensure that you perform all of the available security checks for phone / mail sale.
 - 1. Press **F4** → Phone / Mail Sale.
 - 2. Enter the dollar amount and press OK.
 - 3. Enter the account number and press OK.
 - **4.** Enter the **expiry date** and press **OK**.
 - **5.** Indicate the order type; a **phone** or a **mail order**.
 - 6. If it is a phone order, enter the three or four-digit CVD number and press OK.
 - 7. The screen shows that authorization number, the transaction total and the receipts print.

Force post (sale or phone / mail)

This option is only used when you can't process a credit card sale normally through the network whether due to communication problem or that the force post is requested via the terminal.

Before you perform this transaction you must call the TD Merchant Help Desk at **1-800-363-1163** and receive an authorization number.

- 1. Press **OK** → Force Post → Force Sale or Force Ph/Mail.
- 2. Enter the dollar amount and press OK.
- **3.** Perform one of the following payment methods for the credit card in question: **Swipe** (only for Sale transactions) or **Manual entry**.

<u>Swipe</u>

a) Verify the card info with what is on the screen and press **OK**. Go to step 4.

Manual entry

- a) Enter the account number and press OK.
- b) Enter the expiry date and press OK.
- c) A manual imprint of the credit card is required. Make the imprint and press **OK**.
- d) Enter the CVD number and press OK. Go to step 4.
- **4.** Then enter the authorization number and press **OK**.
- **5.** The screen shows that authorization number, the transaction total and the receipts print. The customer **must** sign the signature field on the merchant copy for a force post sale transaction.

Void

This transaction is used to correct a previously entered transaction from the terminal in the current, open business day. You can also use Transaction Recall to recall and cancel/void a transaction based on information other than the trace number.

If you have closed the business day that the transaction was performed in, you can only perform a return. The option to void the transaction is no longer available.

- 1. Press OK → Void.
 - Enter the **trace number** for the transaction to be voided and press **OK**. If you are voiding a debit transaction you will need the card that it was performed on.
- 2. Verify that this is the correct transaction: **Void** or **Back**. If you select back, you can enter a new trace number to void.
- **3.** The voided transaction receipts print.

Transaction recall

This option recalls a transaction so that you can view or void it for any transactions that were performed in the current open batch. If a day close has been completed you can only recall transactions after the last day close or batch close. Pre-authorization transactions are covered in our online documentation at www.tdmerchantsolutions.com/posresources.

- 1. Press the **Admin** key → Trans Recall Menu.
- **2.** Select one of the following options:

by Detail

This recalls the details all of transactions in the open batch.

a) Scroll to the **desired transaction** and press **F4**. Go to step 3.

by Amount

This recalls any transaction for the entered dollar amount in the open batch.

- a) Enter the dollar amount and press OK.
- b) If more than one transaction appears, select the desired one and press F4. Go to step 3.

by Account # (credit cards only)

This recalls any transaction for the entered card account number in the open batch.

- a) Swipe the credit card or enter the card account number and press OK.
- b) Select the transaction and press F4. Go to step 3.

by Invoice

This recalls the transaction for the entered invoice number.

a) Enter the invoice number that you want to recall and press **OK**. Go to step 3.

by Trace

This only recalls the transaction connected to the trace number in the open batch.

- a) Enter the **trace number** that you want to recall and press **OK**. Go to step 3.
- **3.** Verify that the it is the correct transaction information on the screen and do one of the following:
 - a) Select **Void** to cancel the transaction and the voided receipts print.
 - b) Select **Back** to select a different transaction.
 - c) Press Cancel to exit the screen.

Return

You can only perform a return on a transaction that has already been submitted for reimbursement.

Debit returns are disabled by default. If you wish to activate debit returns on your terminal please call the TD Merchant Solutions Help Desk at **1-800-363-1163**.

- 1. Press OK → Return.
- 2. Enter the dollar amount and press OK.
- 3. Customer confirms the dollar amount and presses Yes or No.
- 4. Perform one of the following: **Insert**, **Swipe** or **Manual entry** the card in question.

Insert credit card

- a) Verify the card info with what is on the screen and press **OK**.
- b) The customer may be required to enter their PIN. Go to step 5.

Swipe credit card

a) Verify the card info with what is on the screen and press **OK**. Go to step 5.

Manually enter credit card

- a) Enter the account number and press OK.
- b) Enter the **expiry date** and press **OK**. This is four digits in length.
- c) Indicate if the return is for a phone / mail sale: Yes or No. Go to step 5.

Insert / swipe debit card

- a) The customer selects the account to use: CHQ or SAV.
- b) The customer enters their PIN and presses OK. Go to step 5.
- 5. The screen shows that authorization number, the transaction total and the receipts print.

Receipts

Each transaction has a different receipt and most of the information is purely for record keeping. There is important information that you need to be aware of to ensure that your transactions have completed correctly.

Reprinting receipts

- 1. Press the Admin key \rightarrow Reprint Menu and select a reprint option.
- 2. To reprint the **last receipt**, select which copy you want to reprint (**Merchant**, **Customer** or **Both**) and press **OK**.
- The receipt reprints and is noted as a duplicate.OR
- 2. To reprint a previous receipt, select one of the following options:

All

a) Scroll through the available receipts, select the desired one and press OK. Go to step 3.

Invoice

a) Enter the invoice number and press OK. Go to step 3.

Account

a) Swipe the card or enter the account number and press OK. Go to step 3.

Approval Code

- a) Enter the approval code and OK. Go to step 3.
- 3. Select which receipt to reprint (Merchant, Customer or Both) and press OK.
- **4.** The receipt reprints and is noted as a duplicate.

Receipt examples

Transaction type				
С	Online chip card transaction	RF	Contactless transaction	
CN	Chip card No Signature Required transaction	S	Swiped mag card transaction	
СО	Off-line chip card transaction	SC	Swiped chip card fall back transaction	
M	Manually entered mag card transaction	SN	Swiped No Signature Required transaction	
MC	Manually entered fall back of a chip card transaction			

Card type				
AM	American Express	MC	MasterCard	
DP	Debit	VI	Visa	
DS	Discover/Diner			

Important information		
Trace #	The trace number associated with the transaction	
Inv #	The invoice number associated with the transaction.	
Auth #	The authorization number associated with the transaction	
Signature	The card issuer determines when a signatures is required for a transaction so ensure that the client signs these receipts.	
Approved	Always ensure that the transaction was approved as it could be DECLINED .	

Credit Card

Merchant Name Address City, Province Merchant Number Terminal ID

SALE

06-16-2016 12:41:02 Acct # 455763*****1632 **S**

Card Type VI

Name: nnnnnn Trace # 010103 Inv # 109

Auth #089090 RRN 001003099

Sale \$9.00

TOTAL \$9.00

Retain this copy for your records

Merchant copy

Debit Card

Merchant Name Address City, Province Merchant Number Terminal ID

SALE

06-16-2016 12:41:02 Acct # 476173******0010 **C**

Card Type DP

Name: nnnnnnnn A000000000980840

Trace # 060072 Inv # 124

Auth #008635 RRN 001003099 TVR 8000048000 TSI 6800

TC 98952D8874F69BD1

Sale \$25.00

TOTAL \$25.00

00 APPROVED-THANK YOU

Retain this copy for your records

Merchant copy

Business Day Functions

Performing a day close

You have a deadline to perform a day close. This is called your balancing window and it is set on the system. If your day close is done before your balancing window ends, you'll receive same or next business day deposit for credit and debit card totals. Otherwise, they will be forwarded to the next business day.

A day close is automatically performed on your terminal every three to five business days if one isn't performed sooner by you.

- 1. Press the Admin key → Business Day Menu → End of Day.
- 2. Confirm that you want to close the business day: Yes or No.
- 3. The end of day reports print.
- **4.** The terminal reboots.
 - If a lot of transactions have been conducted during the day, or you are using a dial-up connection, this process may take a while.
 - Once the process is started, ensure no one interrupts it by processing any transactions, pressing any buttons or disconnecting your Internet service on the terminal in question.

You must close your business day on **each terminal** in order to maintain accurate records and balance your accounts. Closing the business day is important as it:

- Sends any stored transactions (SAFs).
- Closes all open batches.
- Prints selected reports.
- Checks for mail, and downloads.
- Downloads available updates.
- Starts a new business day on the terminal by opening a new batch.

A batch is a group of transactions that you must submit to the issuer to accept in order for you to be paid. Once you close the batch or perform and end of day, these transactions are sent to the issuer for settlement and then they will deposit the funds into your account.

Configuration

Changing the terminal communication method (TD iWL252)

If you have changed your Internet connection at your place of business, you may have to change your terminal connection settings so that you have a fall back connection in case your primary fails. Please refer to the chart below for the best option for your communications.

l have a dial connection	I have an Ethernet connection	Suggested communication setting
No	Yes	Ethernet Only
Yes	No	Dial Only
Yes	Yes	Eth w/dial F'back

- 1. Press the Admin key → Setup Menu → Communications Menu → Comms Type Setting.
- 2. Select one of the following: Ethernet Only, Dial Only, Eth w/dial F'back or Dial w/Eth F'back and press OK.

More features and functionality

There are more ways to configure your terminal such as:

- User management
- Software downloads
- Communication options
- Terminal settings
- Transaction options

For more information, please visit our online documentation at www.tdmerchantsolutions.com/posresources.

Reporting

The following reporting options are split into different groups, business day, batch and customized. You have access to all of the business day and batch reports, and these will be covered in this Guide. Please see our online documentation for customized reports at www.tdmerchantsolutions.com/posresources.

Business day reports

1. Press the Admin key → Business Day → Business Day Reports and then select a report.

Report	Instructions	Provides
Terminal Detail	DISPLAY or PRINT your report.	all transactions for the current business day.
Terminal Balancing	Same as above.	transactions for the current business day.
Day Subtotals	Select whether the report is for an individual ID or all IDs.	transactions by operator ID and for the current business day.
	DISPLAY or PRINT your report.	
Operator Detail	Same as above.	transactions by card type, operator ID for the current business day.
Operator Balancing	Same as above.	transactions by card type, operator ID for the current business day.
Outstanding SAF	DISPLAY or PRINT your report.	all stored transaction details that have not been sent for settlement.

Batch reports

1. Press the Admin key → Business Day → Batch Reports and then select a report.

Report	Actions	Provides
Terminal Detail	Select which batch you want to review PREV or CURRENT and how you want to receive it DISPLAY or PRINT .	transaction details by card type by current or previous batch.
Terminal Balancing	Same as above.	transaction details by card type by current or previous batch

Customized reports

These reports are for all transactions performed for the business days currently stored in the terminal. These reports can only be accessed by supervisors or managers. The following chart describes what each report displays.

Report	Report details	
Transaction Details	By business day By card type By operator	Detailed transactions can be accessed for a maximum of 10 business days
Totals	By transaction type By card type	Totals can be accessed for a maximum of 45 business days

- 1. Press the Admin key → Business Day Menu → Customized Reports.
- 2. Enter the Manager ID and press OK.
- 3. Enter the Manager Password and press OK.
- **4.** Select one of the following options:
 - a) Transaction Details
 - b) Totals
- **5.** Do one of the following:
 - a) Enter an Operator ID and press OK.
 - **b)** Press **OK** for a report showing all operators.
- **6.** Enter the **start date** for the report and press **OK**.
- 7. Enter the **start time** for the report and press **OK**.
- **8.** Enter the **end date** for the report and press **OK**.
- **9.** Enter the **end time** for the report and press **OK**.
- 10. Decide how to retrieve the report (**Display** or **Print**). If you select **Display**, you will be able to cycle through the details by selecting **Prev** or **Next**. If you select **Print**, your report will begin to print.

EMV reports

The EMV reports are used for troubleshooting and you only print these out if requested by the Help Desk. Also, if you do print these out, some can be quite long so repeated printings will make you use more paper than normal.

Troubleshooting

If you're unable to resolve the problem after performing the following steps, please contact the TD Merchant Solutions Help Desk at **1-800-363-1163**.

What problems can I easily resolve?

Action	Required	
1.	There was a communication failure after the transact was initiated.	
2.	Verify your connections (Internet, dial up, terminal cables, etc.).	
3.	Press Cancel and try again.	
1.	Try a different card. If this card can be read, the problem is with the first card.	
2.	Use a cleaning card to clean the card reader.	
1.	Ensure that the power cable is firmly connected to the power port and the electrical outlet.	
1.	Swipe the card more quickly or more slowly or from the top of the reader towards you.	
2.	Request another form of payment. If this card can be read, the problem is with the first card.	
3.	Use a cleaning card to clean the problem card reader.	
1.	Ensure there is paper and that it is loaded correctly in the device.	
1.	Ensure that the paper feed is clear and that the paper roll is seated correctly.	
2.	Ensure the printer lid is completely closed.	
	1. 2. 3. 1. 2. 1. 1. 1. 1.	

Why don't I see a connection icon on the Idle screen?

TD iWL252

There are two communication methods for the TD iWL252 solution: dial-up / phone line and DSL. If you don't see the green network icon (呂內) for DSL or the green phone icon for dial-up, you can quickly check the following:

<u>Dial-up / phone line connection</u> DS

- 1. Is your phone line working properly?
- 2. Ensure the terminal is securely plugged into the communication adapter.
- **3.** Ensure the communication adapter is securely plugged into a phone outlet.

DSL Internet connection

- 1. Is your Internet connection working properly? Verify this with another device.
- 2. Is your modem / router working correctly? Unplug and plug back in your modem / router and wait for three to four minutes.
- **3.** Ensure the terminal is securely plugged into the communication adapter.
- **4.** Ensure the communication adapter is securely plugged into a phone outlet.

TD iWL255

If you don't see the green 3G icon, try the following:

- Have you made physical changes to your location? New walls or electronic
 devices near the terminal may inadvertently reduce the wireless signal strength.
 Try walking around your place of business to see if you are able to receive a signal.
- Has something changed to the environment outside your place of business? A
 new building may also reduce or block your signal strength. Try walking around
 your place of business to see if you are able to receive a signal.
- There may be an issue with the wireless phone network.

What is the signal strength?

The signal strength is represented by five to zero bars. Your terminal should always show at least one in order to be able to complete transactions and ideally it should be a minimum of two bars.



If the terminal is experiencing low or no signal strength, check the following:

Has the Bluetooth base become loose or unplugged? (TD iWL252 only)

Ensure the base is securely plugged into an electrical outlet.

Have any obstacles or electronic equipment been placed around the base or the terminal? (TD iWL252 and TD iWL255)

If you have made physical changes to your location, such as adding a new wall or piece of equipment, you may need to have the base moved to accommodate this change. Please contact the TD Merchant Solutions Help Desk to assist with this if necessary.

What can interfere with Bluetooth connectivity?

The biggest issue is that the frequency range (2.4GHz) used by Bluetooth is shared by other equipment and can be blocked by certain materials. There are steps that you can take that will minimize Bluetooth connectivity issues. They are:

Distance between the terminal and the base

Ensure that you keep your terminal and base in the same room if possible. Obstacles such as walls or furniture may weaken or block the Bluetooth signal.

2. Signal interference

Bluetooth uses the 2.4GHz frequency range which is shared by other devices such as:

- Microwaves
- Wi-Fi devices (routers, VoIP phones, wireless cameras)
- Fluorescent office lighting
- Some cordless phones and baby monitors

To avoid connectivity and data issues, avoid going near these devices when using the TD iWL252 solution. Of course, you can't always avoid sources of interference such as Wi-Fi or fluorescent lighting. To accommodate this, Bluetooth is able to adapt to some interference from multiple sources depending on its strength. But, if you encounter too many sources of interference at once, your devices may not be able to adapt and they could lose connectivity.

What can interfere with 3G connectivity?

The 3G (cell towers) signal is blocked by certain materials. Buildings (new or existing) have a large amount of concrete or brick and may cause connection issues. As well, new physical barriers added to your workplace (walls with metal frameworks and electrical wires) may also cause interference for your TD iWL255 terminal. Be aware that if you modify your workplace that you may be introducing signal interference.

Why isn't my terminal charging?

TD iWL252

- 1. Ensure the terminal is seated firmly in the base? Then, check to see if the charging icon appears in the top-right of the screen. If it doesn't, go to step 2.
- 2. Ensure that the bases' electrical outlet has power. If it is, go to step 3.
- **3.** Ensure that the power pack is fully inserted into the power outlet. Is the terminal charging? If not, go to step 4.

- **4.** Ensure that the power cable is fully inserted into the base. Is the terminal charging? If not, go to step 5.
- 5. Use charging cord included in your welcome kit. Plug this into an electrical outlet and plug the other end into the charging port on the left side of the terminal. It is covered by a grey rubber flap that can easily be lifted with your thumbnail.

TD iWL255

1. Use charging cord included in your welcome kit. Plug this into an electrical outlet and plug the other end into the charging port on the left side of the terminal. It is covered by a grey rubber flap that can easily be lifted with your thumbnail.

If after trying these steps your terminal still does not charge, please contact the TD Merchant Solutions Help Desk.

What do I do if there's a power outage?

TD iWL252

The terminal will not be able to process transactions without power. Once the power has been restored, you do not need to take any steps to restart your Bluetooth base. It will automatically come online and create a connection with your terminal if it is in range. If a transaction was interrupted due to battery/power failure, please perform the transaction again when power is restored.

TD iWL255

A terminal with battery power will still work and be able to perform transactions unless the local cell tower does not have power as well.

Reference

Maintaining the terminal

- Don't place it on a magnetized pad this will cause it to malfunction.
- Routinely clean it with a damp cloth so that spills don't get into the inner workings.
- Use TD-approved cleaning cards for the chip and magnetic card readers.
- This also includes the Bluetooth base for the TD iWL252.

Storing the terminal

- They must be stored in temperatures between 0° and 50° Celsius.
- Do not leave it outdoors, or in your vehicle, (summer or winter) for an extended period of time as this will have an adverse effect on battery performance.
- This also includes the Bluetooth base for the TD iWL252.

Entering letters and special characters

Whenever you have are requested to enter a letter or special character, such as a receipt banner or creating a user ID, follow these steps. Press **correction** to change any entry.

Letters		Spaces		Specia	Special characters	
1.	Press the key that has the desired letter on it. For example, press 2 key to enter C .	1.	Press 0 key.	1.	Press the Admin key.	
		2.	Press the F key twice.	2.	Press the F key until the desired special character appears on the	
2.	Press the F key until the desired letter is displayed.				screen.	

Call Centre Information

Please call the TD Merchant Solutions Help Desk at **1-800-363-1163**. We would be happy to answer any questions you may have.

Authorization:

24 hours a day, seven days a week

Terminal Inquiries:

24 hours a day, seven days a week

General Merchant Inquiries:

Monday - Friday, 8 a.m. - 8 p.m. ET

Printer / Stationery Supplies:

Monday - Friday, 8 a.m. - 5 p.m. ET

Documentation Portal

This Guide covers the most commonly used information in order to get you started. Your terminal has more features and functionality to explore on our documentation portal www.tdmerchantsolutions.com/posresources.

